
Subject: Re: ** Pi chart request **

Posted by [Wayne Parham](#) on Fri, 07 Oct 2005 03:10:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

Impedance at low frequencies will drop at some points, but will rise again at the resonance modes. At these frequencies, shunt impedance will reduce Z_{max} and it will tend to remain more constant. It's a consequence that acts in your favor.
