Subject: Re: Speaker Insulation
Posted by Wayne Parham on Fri, 14 Oct 2005 05:46:11 GMT
View Forum Message <> Reply to Message

You want to reduce MF standing waves without changing other characteristics too much. The amount and location of stuffing is very important in some cabinets, less so in others. It depends largerly on cabinet dimensons and passband wavelengths.