

---

Subject: Re: Speaker Insulation

Posted by [Wayne Parham](#) on Fri, 14 Oct 2005 05:46:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You want to reduce MF standing waves without changing other characteristics too much. The amount and location of stuffing is very important in some cabinets, less so in others. It depends largely on cabinet dimensions and passband wavelengths.

---