

---

Subject: Forget the spades

Posted by [GarMan](#) on Mon, 24 Oct 2005 12:43:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Spades are poor connectors. Solder the wires directly to the drivers instead. If you want the option to disconnect the drivers, then solder a 4" length of wire to the driver and connect the bare wire on the other end with electrical screw caps. Twist it in tight.

---