Subject: Forget the spades
Posted by GarMan on Mon, 24 Oct 2005 12:43:27 GMT
View Forum Message <> Reply to Message

Spades are poor connectors. Solder the wires directly to the drivers instead. If you want the option to disconnect the drivers, then solder a 4" length of wire to the driver and connect the bare wire on the other end with electrical screw caps. Twist it in tight.