

---

Subject: Re: Details...

Posted by [one\\_speed](#) on Mon, 28 Nov 2005 20:11:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Sorry, I honestly know better than that...Are you comfortable with pushing it to about 3.5 cu. ft. total? My thought is that this would work as a balance of pushing the envelope just a bit, yet trying to avoid the boominess.If not and you think that's not the best direction, let's run with 3 cu. ft. Perhaps that's the better way to go.Thanks again Wayne, I really appreciate your opinion in this matter. Speakerman (Ron) was right, you are the man!

---