Subject: Re: Pre Compensation Load on X-OVERS and L-Pads
Posted by Wayne Parham on Fri, 06 Jan 2006 14:48:53 GMT
View Forum Message <> Reply to Message

The components work together to form the overall response curve. A simple speaker crossover calculator like what you might find on a website doesn't do very much, and doesn't take reactive loads into consideration. Best to keep studying AC circuits, and you'll gain a real appreciation of Spice.