Subject: Re: tower pic
Posted by Bill Epstein on Sun, 08 Jan 2006 23:33:28 GMT
View Forum Message <> Reply to Message

It's so hard to know how much glue to use on a mitered joint. Ancient trick for any type of joint is to brush a 3 lb cut of shellac on the wood near the joint. The glue won't stick to it and alcohol is the solvent.Better is to final finish, stain and topcoat the entire panel before glue up. After all, the glue-up ends the construction and chances to mar the finish. Glue won't stick to varnish or poly or oil, either.Never wipe glue off raw wood. That let's it enter the pores, especially with a wet rag. Let it dry and then scrape it off.Hat's off to you for screwing up only the hidden edges:)