

---

Subject: Re: Upon further review

Posted by [SteveBrown](#) on Mon, 19 May 2008 20:11:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

How about covering the too-easy-to-melt insulation with a sleeve of teflon, of correct diameter? You solder the shield connection first, right? Then you could even wrap it in teflon tape for a bit better heat and insulation, maybe.

---