

---

Subject: Re: Partitioning layer of insulation

Posted by [Wayne Parham](#) on Thu, 16 Mar 2006 21:51:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It's hard to say. In general, the thinner the layer, the less it does. Absorbent material is best

the absorbent material thicker or space it away. The lower you go, the thicker the padding would have to be. But if that requirement would result in having too much fill, spacing it out becomes a better option. If the crossover point is low or the box is small, it doesn't matter too much but if that isn't the case and standing waves can setup in the midrange, sometimes a partitioning layer or two is the best way to go.

---