
Subject: Re: 10" horn loading

Posted by [Wayne Parham](#) on Mon, 24 Apr 2006 23:13:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

You can do that; It's called reactance anulling and is common practice on basshorns. But I didn't works well with any rear chamber larger than 0.5ft³. In practice, I don't like the rear chamber to be open because I don't want the rear wave to be presented to the room and interact in any way, so I like using the unused space in the midhorn cabinet as a rear chamber and filling it with absorbent material.
