Subject: Re: Glue it
Posted by Bill Epstein on Mon, 01 May 2006 10:33:00 GMT
View Forum Message <> Reply to Message

Use drywall adhesive and just a nail or screw at top and bottom of panels. Keeps the panels from dishing in and out with the studs which are never perfectly aligned. And less sanding.