

---

Subject: Re: Glue it

Posted by [Bill Epstein](#) on Mon, 01 May 2006 10:33:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Use drywall adhesive and just a nail or screw at top and bottom of panels. Keeps the panels from dishing in and out with the studs which are never perfectly aligned. And less sanding.

---