

---

Subject: Re: Tower 2

Posted by [GarMan](#) on Wed, 07 Jun 2006 19:35:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Roland, You access the inside of your finished enclosure through the driver cut-out. If you plan on taking the driver on and off frequently, use t-nuts and bolts instead of woodscrews. Gar.

---