

---

Subject: Re: Frequency response slope question  
Posted by [Wayne Parham](#) on Wed, 21 Jun 2006 20:03:04 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

If you're looking for a generic answer, an easy way to rolloff highs is with shunt capacitance. Change the value of capacitance to affect where it starts; Resistance can be placed in series with

tweeter compensation circuit. Remove the bypass capacitor and possibly increase attenuation. desired. There's a chart showing what resistors to use in the crossover document.

---