

---

Subject: Re: 4 Pi Cabinet

Posted by [Norbert](#) on Wed, 12 Jul 2006 20:29:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Gar, Don't worry about not getting back to me sooner... all is well. You brought up a good point in that the relationship between center of the HF driver and the woofer needs to stay constant (and Wayne confirmed that with all that mathematical calculation -thanks Wayne). What this means is that I need to be careful when building the enclosure to house the horn. So goodbye to fancy horns such as these ones: <http://www.acoustichorn.com/> I ended up using BB-ply from Commonwealth lumber. Getting the 5x5 wood home was quite a challenge... I ended up putting the wood on the roof rack of the van. To install the T-nuts, do I just drill the hole the size of the cylindrical barrel and let the pressure of the screw drive the prongs into the wood? Thanks, Norbert

---