Subject: Re: Blow Fuse!
Posted by Tuffer on Mon, 22 Jan 2007 18:50:57 GMT
View Forum Message <> Reply to Message

So a polyswitch with a trip current of around 2.5a would be a good bet to go in parallel with the stock lamps ?