

---

Subject: Re: Blow Fuse!

Posted by [Tuffer](#) on Mon, 22 Jan 2007 18:50:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

So a polyswitch with a trip current of around 2.5a would be a good bet to go in parallel with the stock lamps ?

---