

---

Subject: Re: Blow Fuse! (2)

Posted by [dB](#) on Mon, 22 Jan 2007 22:51:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I forgot to say that you must replace (soldering back) the CAP that comes with the woofer network of 10uF, to be used with the xover in this case of points 1. 2. and 3. that I posted a few minutes ago. Best Regards

---