

---

Subject: You've got mail! (And a few answers)

Posted by [Wayne Parham](#) on Sun, 11 Mar 2007 03:47:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I would prefer to see the speakers a little lower than 26". They'll work OK there, but floor bounce will give you a notch at 125Hz. Move the speakers down a bit and the notch will go away. It isn't a deal breaker, but I'd prefer the speakers to be lower than that, maybe on stands a few inches to

PicsWhen you get the plans, you'll see that cabinet construction is pretty basic. You can use butt joints, which are as simple as it gets. Just flat panels glued together at the edges. No diagonal cuts, no dados. You will want a brace from front baffle to rear, in between the woofer and tweeter. You can also run one from side to side. Put R13 insulation on the bottom, side and rear of the cabinet interior. That's all there is to it!

---