
Subject: Re: Discrete resistors vs. variable L-Pad
Posted by [Wayne Parham](#) on Fri, 06 Apr 2007 16:34:20 GMT
[View Forum Message](#) <> [Reply to Message](#)

Some L-Pads are made to hold their impedance constant, but others are really just potentiometers. The latter will cause crossover characteristics to shift as the slider is moved.
