

---

Subject: Re: Midhorn bracing

Posted by [Wayne Parham](#) on Tue, 10 Jul 2007 15:53:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Loosely pack the sides, top and bottom surrounding the flare with insulation:

Midhorn packed with insulation and rubber ball brace in place

The picture above doesn't show the gasket, but one is used to seal the access panel. A suitable material for this purpose is PVC sheet rubber, commonly used for shower pans. You can get it at most builder's supply houses and cut it to fit. Makes excellent gasket material.