

---

Subject: Easy to add Post-assembly Bracing  
Posted by [Skip Pack](#) on Thu, 09 Aug 2007 16:04:44 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I've used 1" 'dowels' several times -- available from HomeDepot. Cut them to length, see if you can straighten them into position, if not sand the ends slightly and try again. Once you have a fit, take them out, smear glue on both sides and put them back. Once you see/feel what's vibrating, you get a pretty good idea about where to put them. Skip

---