

---

Subject: Re: Impedance rise in horns

Posted by [Bill Wassilk](#) on Mon, 14 Jan 2008 17:32:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Since your only going for 1 frequency why not just build a 6th order bandpass box and have it peak at that frequency. The boxes would be a lot smaller and you could use more of them for the SPL's. That's why some bandpass boxes are considered 1 note boxes depending on how there designed.

---