

---

Subject: Re: Mounting Eminence Driver

Posted by [Wayne Parham](#) on Sun, 24 Feb 2008 23:07:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

When I use T-Nuts, I usually use 10-32 size with button head or hex head screws. But for the

these fasteners: Black pan screws for mounting small drivers T-Nuts are good when post-construction serviceability is a concern, like for prosound speakers. But if you won't be going inside your speakers a lot, these screws are fine. They look good and will hold until about 20 loosening/tightening cycles, when the wood will stretch enough to tear through.

---