

---

Subject: Finishing details

Posted by [Wayne Parham](#) on Thu, 03 Apr 2008 00:05:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Damping is done by filling the sides with R11 or R13. Brace each flare with a wedge-shaped piece between the flare panel and the cabinet side, top or bottom. Use a rubber ball to preload the access panel.

Check out these posts for more info:

Midrange Horn

Midhorn Bracing

Gaskets

Rubber Ball Brace