

---

Subject: Re: R11/13??

Posted by [Wayne Parham](#) on Tue, 22 Apr 2008 23:58:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

On the midrange cabinet, just loosely fill the rear chamber. On the bass bin, put it on one side, top and face. Also put two pieces spanning the cross-section along the braces, sort of dividing the cabinet into thirds.

---