Subject: Re: Circuit Protection Posted by Wayne Parham on Mon, 05 May 2008 04:59:36 GMT View Forum Message <> Reply to Message

Solder a couple of 211-2 automotive bulbs in parallel, and put them in series with the tweeter circuit, ahead of capacitor C2. That will act as a limiter, because the bulbs will start to glow at high power, which will increase series resistance.

Page 1 of 1 ---- Generated from AudioRoundTable.com