
Subject: Re: Transporting 2-way speaker box to Open Baffle

Posted by [ttan98](#) on Sat, 12 Jul 2008 14:50:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

I am not such whether you can give some suggestions on where to start on the x-over design. I promise not to ask you too many questions once you give some suggestions. The current x-over design using digital x-over, is at around 1.6Khz, 3rd order Butterworth filter (Hp and LP), the horn I am using is 90*50 degree directivity. This horn is identical to the one used in the econowaveguide at Karma Forum. The woofer is 15" JBL. Any suggestion on a start to x-over design is welcome, eg LR or butterworth and approx x-over frequency. Thanks. many thanks.
