

---

Subject: Re: Bass bin as sub and reckhorn

Posted by [Wayne Parham](#) on Sun, 20 Jul 2008 17:45:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

slow gradual lower rolloff which never gets boomy, even when parameters shift from use at high power levels or when the loudspeaker is used in small rooms. That's usually plenty for most people, and I'd say 95% of the people use them that way. In fact, I can't think of anyone that's bothered to augment them with a sub. It's just that a subwoofer that's tuned for lower frequency

going strong at that frequency and will go all the way down to 20Hz or below. If you want the real deep bass at earthshaking levels, like for home theater, then adding subs is an easy way to do it. They're also very useful for smoothing room modes in problem rooms with no damping. In that case, you're not looking for additional output at all, you're just filling in holes caused by exaggerated room modes. Either way, the subs are fairly easy upgrades, if wanted or needed.

---