

---

Subject: Re: stuffing midhorn back chamber?

Posted by [Wayne Parham](#) on Thu, 14 Aug 2008 19:50:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Loosely fill the rear chamber with R11 or R13. Here is a post with the links you're talking about, with the rubber ball brace and some other useful tips:

Finishing details

---