

---

Subject: Re: High Efficiency

Posted by [Bill Epstein](#) on Sun, 28 Sep 2008 01:35:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The real issue is the output of your pre-amp vs, the sensitivity of your amp. The amp must be very sensitive, (do you have the figures?) and the passive must have a strange attenuation taper to be worse than the pre-amp. To find the answer, post the output in volts of your source (CD player?), the output of your pre-amp in decibels and the input sensitivity of your amp.

---