Subject: Re: LAB-12 CROSSOVER ? Posted by Wayne Parham on Tue, 17 Feb 2009 17:48:22 GMT View Forum Message <> Reply to Message

I use an active crossover with 90Hz 12dB/octave low-pass slope. Sometimes, it is good to go a little higher, sometimes a little lower. Don't high-pass the mains, let them blend. The further away the subs are, the lower the low-pass frequency for the subs should be. Sometimes it even helps to reverse polarity.