
Subject: LAB12 driver - why is it so good and efficient?
Posted by [adamzuf](#) on Mon, 13 Apr 2009 15:00:41 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi,I read in speakerplans FAQ that a high EBP is good for horns. However this is not the case with this driver... The low F_s is needed for the horn to go low, but isn't a lower Q_{ts} would make it a faster driver?It also doesn't have tons of BL, however X_{max} is good..Thanks for the helpAdam
