
Subject: Re: midrange horns

Posted by [adamzuf](#) on Fri, 17 Apr 2009 17:06:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

so higher stiffness = higher frequency in which flex starts lower Qts = more control over flex when it starts
How can I know how stiff is the driver? BTW, didn't mean to say you trust things blindly - I trust you not to do that.. I value your work and word and am thankful for your time. Adam
