
Subject: Crossing near F_s

Posted by [goldyrathore](#) on Sat, 25 Jul 2009 15:53:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi,

I am planning to use 3" full range drivers (used as mid) for a 3 way array project. I would like to cross the drivers at their lowest usable frequency to the woofers. The following are the parameters of the drivers

$F_s = 157$, $Q_{ts} = 2.0$.

With such a high Q_{ts} . How low can I cross to the woofer without any audible anomalies?

Thanks in advance,
Goldy
