

---

Subject: Re: 4 Pi Design Questions

Posted by [Wayne Parham](#) on Thu, 21 Jan 2010 03:09:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Generally, ducts that are long and thin tend to develop internal standing waves and those can be a problem. Then again, you can get around them with the right placement and just being long and thin isn't always a problem. In the end, you'll have to measure the cabinet to know for sure.

---