
Subject: Re: 3 Pi subwoofer mounting question
Posted by [Wayne Parham](#) on Mon, 15 Mar 2010 04:13:39 GMT
[View Forum Message](#) <> [Reply to Message](#)

Those gaskets sometimes matter when horn loading, but not when used as a direct radiator. It's usually a clearance issue. In all my designs, I leave the attached gaskets in place, but I don't use the extra one packaged with the driver.
