
Subject: Re: Position of nulls from adjacent sound sources
Posted by [Wayne Parham](#) on Thu, 05 Aug 2010 18:24:13 GMT
[View Forum Message](#) <> [Reply to Message](#)

The crossover frequency is pretty near there, just north of that actually. Keep the driver spacing close, because this sets the position of the forward lobe and the vertical nulls. Don't reinvent the wheel, build it as designed. Lots of work went into refinement and optimization of that loudspeaker.

Crossover optimization for DI-matched two-way speakers, revisited
