Subject: Re: More HornResponse Posted by Wayne Parham on Mon, 13 Dec 2010 05:21:28 GMT View Forum Message <> Reply to Message

You can also build up the area inside - behind the mounting plate and in front of the driver - making an inverse cone to displace some of the front chamber volume. Just be careful not to go to far so that the cone would strike it at high excursion levels.

Page 1 of 1 ---- Generated from AudioRoundTable.com