
Subject: Re: Flush-Mounting Tips Please :)
Posted by [Wayne Parham](#) on Wed, 16 Mar 2011 15:26:54 GMT
[View Forum Message](#) <> [Reply to Message](#)

What we do is to route a groove that is about 1/16" deeper than needed to allow space for a gasket. It should also have about 1/16" gap around the outer edge, so make it 1/8" larger in diameter, i.e. 12-5/8".

You can use any number of things for gasket material, felt, cardboard, etc. I prefer to use PVC sheets. You can get it at any hardware store as shower pan material.