

---

Subject: Re: Rabbet dimensions for flush mounting (4Pi upgraded)

Posted by [Wayne Parham](#) on Mon, 11 Apr 2011 04:17:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You definitely do not want a zero tolerance fit when using wood, or even a really tight fit. Give it as least 1/16" extra, and probably better to oversize 1/8". That little gap you leave isn't much.

---