
Subject: Have a pair of Full range drivers - what to(should) do with it?

Posted by [Eldragon65](#) on Sun, 08 May 2011 19:13:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

What's your thought on enclosure type, also should I ad the tweeter and what type of x-over, or should I utilize 'full range?'

Prefer 1-2 cubic/ft sealed enclosure. Thanks!!! (blue line on chart)

BETSY -K:
Re 5.7 ohms
Fs 49.959Hz
Sd 22.966
BL 5.471
Qms 2.798
Qes .548
Qts .458
Spl 94.6
Vas 82.914L
Mms 9.167g

File Attachments

1) [freq_chart.jpg](#), downloaded 3159 times
