
Subject: Have a pair of Full range drivers - what to(should) do with it?

Posted by [Eldragon65](#) on Sun, 08 May 2011 19:13:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

What's your thought on enclosure type, also should I ad the tweeter and what type of x-over, or should I utilize 'full range?'

Prefer 1-2 cubic/ft sealed enclosure. Thanks!!! (blue line on chart)

BETSY -K:

Re 5.7 ohms

Fs 49.959Hz

Sd 22.966

BL 5.471

Qms 2.798

Qes .548

Qts .458

Spl 94.6

Vas 82.914L

Mms 9.167g

File Attachments

1) [freq_chart.jpg](#), downloaded 3133 times
