

---

Subject: Attaching drivers.

Posted by [justphil](#) on Thu, 19 May 2011 23:52:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

are "T" nuts suggested or are wood screws fine?

Also I know you were using that shower stuff for gasket material. At my work we something called butyl tape. Its a gummy substance they used to use to seal and set windshields in cars. Is something like this a good thing to use?

Thanks,

Phil

---