Subject: Re: 4 Pi Home Theater Build Posted by NWCgrad on Sun, 19 Jun 2011 00:47:57 GMT View Forum Message <> Reply to Message

I have not veneered before and am not sure whether there is a particular order to gluing the sheets to the cabinet. I am planning on starting with the bottom, then both sides and finally the top. Is this order correct? If not, what is the best order?

Will use router with a new flush cut bearing bit to trim.

Thanks for the assistance!

Page 1 of 1 ---- Generated from AudioRoundTable.com