Subject: Re: Signal Wire for 4Pis
Posted by Wayne Parham on Mon, 25 Jul 2011 13:03:32 GMT
View Forum Message <> Reply to Message

Use a good stranded copper conductor that's 16 guage or larger. Only use enough to reach the components, and don't leave a bunch of extra coiled up on the bottom. But do use enough to allow slack for easy service - Make sure there's an extra foot or two so you can easily connect the drivers outside the box before installing them.