

---

Subject: Re: Signal Wire for 4Pis

Posted by [Wayne Parham](#) on Mon, 25 Jul 2011 13:03:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Use a good stranded copper conductor that's 16 guage or larger. Only use enough to reach the components, and don't leave a bunch of extra coiled up on the bottom. But do use enough to allow slack for easy service - Make sure there's an extra foot or two so you can easily connect the drivers outside the box before installing them.

---