

---

Subject: Subwoofer hook-up

Posted by [Bill Epstein](#) on Thu, 04 Aug 2011 20:24:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

With a passive pre I don't have line level out and can't remember which is better/worse: run second set of wire from amp speaker terminals to high level in or single run to sub high-level then to speakers?

I've even heard of running wire from speaker terminals to sub hi-level which would be convenient but wouldn't it change the impedance?

One more thing, following the Diyaudio thread on imaging that became a sub-woofer thread, what would you use to SUM the channels? Geddes wasn't implying that recordings do that, was he?

---