

---

Subject: Re: Midhorn Flat Pack Tips

Posted by [Wayne Parham](#) on Wed, 24 Aug 2011 18:37:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The Miller dowel pins are included. They're just sitting in throat hole cutout, sandwiched in between side panels. If you use them to pin the horn together you won't need to cradle the horn while the glue sets. Just put white glue on every surface, assemble the horn and tap the pins in.

---